



RegO [®] Series Number	Repair Kit Number	Repair Kit Contents
6532A Series	19100-50B	Service valve: complete bonnet assembly, bonnet/stem, O-ring, hand-wheel, self tapping screw
6532A Series	19104-50	Service valve: complete multibonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6532A Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6532A Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly
6532R Series	19104-50	Service valve: complete multibonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6532R Series	19104-80	Service valve: multibonnet upper packing assembly
6532R Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6532R Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly
6533A Series	19100-50B	Service valve: complete bonnet assembly, bonnet/stem, o-ring, hand-wheel, self tapping screw
6533A Series	19104-50	Service valve: complete multi-bonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6533A Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6533A Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly
6533R Series	19104-50	Service valve: complete multi-bonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6533R Series	19104-80	Service valve: multibonnet upper packing assembly
6533R Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6533R Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly
6542A Series	19100-50B	Service valve: complete bonnet assembly, bonnet/stem, O-ring, hand-wheel, self tapping screw

continued



RegO® 6532, 6533, 6542 and 6543 Series DOT ASME Multivalve Repair Kits

RegO® Series Number	Repair Kit Number	Repair Kit Contents
6542A Series	19104-50	Service valve: complete multibonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6542A Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6542A Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly
6542R Series	19104-50	Service valve: complete multibonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6542R Series	19104-80	Service valve: multibonnet upper packing assembly
6542R Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6542R Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly
6543A Series	19100-50B	Service valve: complete bonnet assembly, bonnet/stem, O-ring, hand-wheel, self tapping screw
6543A Series	19104-50	Service valve: complete multibonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6543A Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6543A Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly
6543R Series	19104-50	Service valve: complete multibonnet assembly- bonnet assembly, hand-wheel, self tapping screw
6543R Series	19104-80	Service valve: multibonnet upper packing assembly
6543R Series	6542B-50	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly, upper body
6543R Series	6542B-80	Filler valve: gaskets, spring, spring guide, stem and seat disc assembly