1" Rotogages[®] for Large Mobile and Stationary Containers A9090 Series


Application

Rotogages® are designed to provide an accurate determination of LP-Gas or anhydrous ammonia container contents. They mount in a standard 1" NPT coupling on large mobile or stationary containers.

To operate the Rotogages®, the vent valve is opened and the dip tube rotated slowly from the container vapor space to the liquid space. The difference in appearance of the discharge indicates when the liquid level is reached. Dial readings then indicate the percentage of product in the container.

Features

- Supported design (TS Models) eliminates whipping and the need for internal support hangers.
- Resistance-free nylon bearing inserts reduce friction and promote operating ease.
- Dial face is dual calibrated to provide greater accuracy in reading contents in containers which are not level.
- Interchangeable accessory dials permit interchangeable service between LP-Gas and anhydrous ammonia.



Materials

| Body | Steel |
|------------|-----------------|
| Stem | Steel |
| Dip Tube | Seamless Steel |
| Indicator | Malleable Iron |
| Dial Plate | Aluminium |
| Vent Stem | Stainless Steel |

Tubes for use with A9090 Series Rotogages Cut to length required.

| Service | Part Number |
|------------|-------------|
| Up to 48" | A9091-M24.0 |
| Up to 72" | A9091-M36.0 |
| Up to 96" | A9091-M48.0 |
| Up to 120" | A9091-M60.0 |
| Up to 144" | A9091-M72.0 |





A9091-18LX

Rotogage® Dials


Ordering Information

| Part Number | Service | Container Size | |
|-------------|---------|------------------------|--|
| A9091-18L | LP-Gas | All Sizes | |
| A9091-18LX* | LP-Gas | Over 1200 U.S. gallons | |
| A9091-18N | NH3 | All Sizes | |


^{*} Dial permits higher filling level, per NFPA 58,

1" Rotogages[®] for Large Mobile and Stationary Containers

For Small Mobile or Stationary Containers A9091R and A9092R Series




For Large Mobile or Stationary Containers A9093TS, A9094TS and A9095TS Series





For Large Stationary Containers 9093RS, 9094RS and 9095RS Series





Ordering Information

| | | (_ | For Container Inside Diameter | | |
|-------------------------------------|-----------------------------------|-----------------|-----------------------------------|-----------------|----------------|
| Part Numb | er | Ellipsoid | Ellipsoidal Heads Hemispherical H | | erical Heads |
| For Mobile or Stationary Containers | For Stationary Containers Only | Side Mounted | End Mounted | Side Mounted | End Mounted |
| A9091R | - | 30" - 45" | 30" - 75" | 30" - 45" | 30" - 45" |
| A9092R | - | 46" - 61" | 76" - 108" | 46" - 61" | 46" - 61" |
| A9093TS* | A9093RS | 62" - 79" | 109" - 147" | 62" - 79" | 62" - 79" |
| A9094TS* | A9094RS | 80" - 99" | - | 80" - 99" | 80" - 99" |
| A9095TS* | A9095RS | 100" - 147" | - | 100" - 147" | 100" - 147" |

" Supported Design NOTE: The dip tube must be cut to the required length(½" of container inside diameter minus 5%").



J