



100 RegO Drive, Elon NC 27244 www.regoproducts.com

January 2024

**RegO** ® Field Topics

**Regulator Freeze-ups** 

**Field Topics** are intended to provide useful information to the network of authorized LP-Gas and Anhydrous Ammonia distributors regarding the proper use of RegO® products. **Warning Bulletins** covering many of the hazards involved are available from RegO for more detailed information. These bulletins can be found in our **L-500**, **RPT-102** and **NH3-102** catalogs. Neither the Field Topic or the Warning Bulletins are intended to conflict with federal, state, or local ordinances and/or regulations, which should be observed at all times. This information also is not intended to be a substitute for or to supplement any training in the safe handling and use of propane and related equipment, as required by any applicable law. By providing this material, ECI assumes no responsibility for providing any such training. Only individuals properly trained in the safe handling and use of propane and related equipment should be permitted to do so, and by providing this information, ECI does not assume responsibility for providing such training.

For more information on LP Gas system requirements, refer to Liquefied Petroleum Gas Code (NFPA 58), National Fuel Gas Code (NFPA 54), National Propane Gas Association Safety Handbook, the RegO LP-Gas Serviceman's Manual L-545, RegO catalogs L-500/RPT-102/NH3-102, ANSI K61.1 Safety Requirements for Storage and Handling of Anhydrous Ammonia, as well as any applicable local codes and ordinances.

## **Regulator Freeze-ups**

Although it is rare for a RegO regulator to freeze up it can happen when there is excessive moisture in LP gas. The freeze up occurs when moisture in the gas condenses then freezes on the cold surface of the regulator nozzle. The nozzle becomes cold when high pressure gas expands as it exits the nozzle into the regulator body.

These conditions can happen in older as well as newer LP-Gas containers when heating demands are higher during colder temperatures. Freeze-ups can also occur in pigtails that are kinked or bent where free flow of the LP-Gas is restricted. These freeze-ups can occur when the moisture, gas flow and temperature combine to create a hazardous condition. Freeze-ups can occur at outside temperatures above 32° F.

All LP-Gas should be checked for moisture content prior to delivery to consumers and proper amounts of anhydrous methanol added if the gas cannot be returned to the supplier. Any container suspected of having excessive moisture should be treated with the proper amount of methanol.









100 RegO Drive, Elon NC 27244 www.regoproducts.com

# What to look for when you encounter a frozen or frosted regulator

### Has the container been purged properly?

A very important step which must not be overlooked by LP-Gas marketers is the importance of properly purging new LP-Gas containers. Attention to this important procedure will promote customer satisfaction and greatly reduce service calls on new installations. Refer to your RegO L-545's serviceman's manual on how to purge a tank properly.

## Has the container been purged properly?

The withdrawal of propane vapor from a vessel lowers the contained pressure. This causes the liquid to "boil" in an effort to restore the pressure by generating vapor to replace that which was withdrawn. Without a properly sized container the container will not be able to produce sufficient vapor pressure thus causing potential regulator freeze up. Refer to your L-545 serviceman's manual to properly size a container.

### Has the container been purged properly?

Whether in a new installation or existing installation LP-gas should be treated properly with Methanol to neutralize moisture. Remember when purging your tank, it is recommended to neutralize the moisture in the LP-Gas cylinder. A rule of thumb for neutralizing moisture in an ASME container calls for the introduction of at least one pint of genuine absolute anhydrous methanol\* (99.85% pure) for each 100 gal. of water capacity of the container.

\*\*\*Do not use methanol to remove ice from the inside of a frozen regulator. Methanol could due severe damage to the diaphragm and seat disc.\*\*\*

Container Type	Minimum Volume Methanol Required
100 lb. ICC cylinder	1/ <sub>8</sub> pt. (2 fl. ozs.)
420 lb. ICC cylinder	1/ <sub>2</sub> pt. (8 fl. ozs.)
500 gal. tank	5 pts. (21/ <sub>2</sub> qts.)
1000 gal. tank	10 pts. (11/ <sub>4</sub> gal.)

<sup>\*</sup> IMPORTANT-Avoid substitutes - they will not work. The secret of the effectiveness of methanol over all other alcohols is its high affinity for water plus a boiling point lower than all other alcohols, and most important: a boiling point lower than water.

#### How is the regulator placed?







#### CLEAN ENERGY SOLUTIONS



100 RegO Drive, Elon NC 27244 www.regoproducts.com

Make sure your regulator is installed higher than the container connection. This will ensure that any liquid droplets that could be formed in the pigtail will drain back into the container.

Replace your single stage regulators with a twin-stage or two-stage system. The chilling action is more severe in single-stage systems as gas expands from tank pressure to 11" w.c. through a single regulator nozzle. Two-stage systems can greatly reduce the possibility of freeze-ups and resulting service calls as the expansion of gas from tank pressure to 11" w.c. is divided into two steps, with less chilling effect at each regulator.

## Check for restriction in your piping system?

Freeze-ups can also occur when there is a restriction of flow in the inlet piping. Check to make sure your pigtails and hogtails are not kinked or bent where free flow of the LP-Gas is restricted. If you are experienced a large vapor load use a hogtail or pipe properly with schedule 80 piping per NFPA 58 requirements.

RegO's L-545 Serviceman's Manual

RegO's L-500 Catalog

PERC/BATTELLE - Recommended proper use of methanol

Should you have any questions or concern, please contact me.

**Paul Courson** Technical Services Manager

O: <u>+1 336.446.7292</u>

Paul Courson

100 RegO Drive, Elon, NC 27244 USA





