

Adhesive Warning Labels 901-400 and 903-400

These adhesive warning labels are intended for application as close as possible to the cylinder valve and/or service valve.

The basic information contained on the label is intended for the benefit of the user of the valves and is not intended to be an "all-inclusive" product warning.

These labels are printed on a heavy duty material with pressure sensitive adhesive backing. The ultra-violet ink stands up well when exposed to the environment.

Part Number	
901-400	Adhesive Label Primarily for Fork Lift Cylinders
903-400	Adhesive Label Primarily for Small DOT Cylinders

DANGER LP GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE WARNING

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS, EVACUATE AREA IMMEDIATELY. CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT.

This container is filled with highly flammable LP-Gas under pressure. A serious fire or explosion can result from leaks and misuse or misbranding of the cylinder and its valve. Do not move, hold or fill the cylinder by its valve. Do not expose to fire or temperatures above 120° F (49° C). The cylinder valve incorporates a Shut-Off Valve and Pressure-Relief Valve. The Pressure-Relief Valve can release a large amount of LP-Gas into the air if the cylinder is exposed to high temperatures—over 120° F (49° C), or (2) overfilled and exposed to a temperature higher than the temperature of the cylinder at the time it was filled. Never attempt to fill this cylinder yourself. Do not tamper with it or attempt repairs. Only trained LP-Gas Dealer personnel should be permitted to fill this cylinder and to repair or replace its valve. Each time the cylinder is filled, the entire cylinder valve must be checked for leaks with a leak detection solution, leaks cause bubbles to grow. The shut-off valve and feed liquid level gauge (if incorporated) must be checked for proper operation. The Pressure-Relief Valve must be checked to ensure that it is completely unobstructed and that it has no physical damage. When in use, keep the service valve fully open. Keep this equipment out of the reach of children. This container must be used only in compliance with all applicable laws and regulations, including National Fire Protection Association Publication No. 58, which is the law in many states. A copy of this Publication may be obtained by writing NFPA, Batterymarch Park, Quincy, MA 02269.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL—DO NOT FILL THIS CONTAINER UNLESS THIS LABEL IS READABLE. ADDITIONAL SAFETY INFORMATION IS AVAILABLE FROM: **REGO** 100 Rego Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

DANGER!

AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL, OR HEAR ESCAPING GAS IMMEDIATELY GET AWAY FROM THIS CYLINDER! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT USE OR STORE IN BUILDING OR ENCLOSED AREA OR OUTDOOR USE ONLY. This cylinder contains highly flammable LP-Gas under pressure. A serious fire or explosion can result from leaks and misuse or misbranding of the cylinder and its valve. Do not carry, hold or fill the cylinder by its valve. Do not expose to fire or temperatures above 120° F (49° C). The cylinder valve incorporates a Shut-Off Valve and Pressure-Relief Valve. The Pressure-Relief Valve can release a large amount of LP-Gas into the air if the cylinder is exposed to high temperatures—over 120° F (49° C), or (2) overfilled and exposed to a temperature higher than the temperature of the cylinder at the time it was filled. Never attempt to fill this cylinder yourself. Do not tamper with it or attempt repairs. Only trained LP-Gas Dealer personnel should be permitted to fill this cylinder and to repair or replace its valve. Each time the cylinder is filled, the entire cylinder valve must be checked for leaks with a leak detection solution, leaks cause bubbles to grow. The shut-off valve and feed liquid level gauge (if incorporated) must be checked for proper operation. The Pressure-Relief Valve must be checked to ensure that it is completely unobstructed and that it has no physical damage. When in use, keep the service valve fully open. Keep this equipment out of the reach of children. This container must be used only in compliance with all applicable laws and regulations, including National Fire Protection Association Publication No. 58, which is the law in many states. A copy of this Publication may be obtained by writing NFPA, Batterymarch Park, Quincy, MA 02269.

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE KEEP CYLINDER OUT OF THE REACH OF CHILDREN

CAUTION—eye protection must be worn when examining the valve. This valve cannot be repaired. If it is obstructed, the entire cylinder valve must be replaced. The Shut-Off Valve may require periodic repair or replacement. Before the cylinder is filled for the first time, it must be purged of air. Total liquid volume must never exceed the amount designated by DOT for this cylinder. If the cylinder has a fixed liquid level gauge, filling should stop the moment a white LP-Gas cloud is emitted from its bleed hole. Keep the vent valve closed tightly at all other times. Keep this cylinder firmly secured in an upright position at all times. Do not lay on its side during transport, storage or use. In other than an upright position, liquid LP-Gas may flow or leak. This liquid can cause skin burns, frostbite and other serious injuries in addition to those caused by fire or explosion. When not in use: Close the Shut-Off Valve. Insert a protective plug (P.O.L. plug) into the cylinder valve outlet. (CAUTION: counter-clockwise thread.) This P.O.L. plug must be inserted each time the cylinder is stored, manually moved, or transported by vehicle.

WARNING!

WHEN MAKING CONNECTIONS TO AN APPLIANCE— 1. Do not use this cylinder without first reading the instructions accompanying the appliance with which this cylinder is intended to be used. 2. Before connecting the Cylinder Valve outlet connection to an appliance, make sure the connection does not contain dirt or debris. These may cause the connection to leak or may impair the functioning of the regulator, creating a hazardous condition. 3. When connecting the Cylinder Valve outlet to an appliance (CAUTION: counter-clockwise thread), make sure the connection is tight. Check for leaks with a high quality leak detection solution (leaks cause bubbles to grow). If the connection leaks after tightening, close cylinder valve, disconnect it from the appliance, insert the P.O.L. plug and immediately return the cylinder, with the Cylinder Valve attached, to your LP-Gas Dealer for examination. This cylinder must be used only in compliance with all applicable laws and regulations, including National Fire Protection Association Publication No. 58, which is the law in many states. A copy of this Publication may be obtained by writing NFPA, Batterymarch Park, Quincy, MA 02269.

DO NOT REMOVE, DEFACE OR OBLITERATE THIS LABEL—DO NOT FILL THIS CYLINDER UNLESS THIS LABEL IS READABLE. 100 Rego Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com Printed in U.S.A. 05-0994-1086 Warning No. 903-400

B

Warning Notice

The following warning information, Part Number 903-500, is included with each shipment of cylinder valves and service valves to the first purchaser of the product from the factory.

This information is intended to be forwarded throughout the product distribution chain. Additional copies are available from REGO® and Authorized Product Distributors.

DANGER READ THIS FIRST WARNING

LP-GAS IS EXTREMELY FLAMMABLE AND EXPLOSIVE
AVOID SERIOUS INJURY AND PROPERTY DAMAGE. IF YOU SEE, SMELL OR HEAR ESCAPING GAS, EVACUATE AREA IMMEDIATELY! CALL YOUR LOCAL FIRE DEPARTMENT! DO NOT ATTEMPT TO REPAIR. DO NOT STORE IN BUILDING OR ENCLOSED AREA. DO NOT USE ON HOT AIR BALLOONS OR AIRCRAFT. Make sure you are thoroughly trained before you attempt any valve installation, maintenance or repair. Improper conditions or procedures can cause accidents resulting in property damage and personal injury. Become thoroughly familiar with NPGA Safety Pamphlet 306 "LP-Gas Regulator and Valve Inspections & Maintenance" and ECIL "Safety Warnings—LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs. Follow their recommendations. Know and understand NFPA Pamphlet 58 "Liquefied Petroleum Gas Code", which is the law in many states. This publication is available from NFPA, Batterymarch Park, Quincy, MA 02269. Following its requirements is essential in the safe use of LP-Gas. Section 4.4 states: persons who transfer liquid LP-Gas, who are employed to transport LP-Gas, or whose primary duties fall within the scope of this code shall be trained in proper handling procedures. Refresher training shall be provided at least every three years and shall be documented. Make sure this valve is the proper one for this installation. Avoid misusing LP-Gas equipment. Apply thread joint compound compatible with LP-Gas on valve external threads only. Make sure compound never comes into contact with other parts of the valve. Install valves by applying force to wrenching flats only. Tighten pipe threads approximately 1 to 1½ turns beyond the hand-tight insertion point using a wrench which avoids damage to other valve parts. Check for damage and proper operation after valve installation. Check that the valve is clean and free of foreign material. Check container/valve connection with a non-corrosive leak detection solution before filling with LP-Gas. Purge container before filling with LP-Gas (refer to the ECIL "LP-Gas Serviceman's Manual for recommended procedure). Test excess flow check valve for proper operation before placing into service. See NPGA Bulletin 113 for recommended procedure. Check outlet connection make-up for leaks with a non-corrosive leak detection solution when placing into service. Rego Products Filler Valves: To prevent damage to the internal checks when it is necessary to utilize an unloading adapter, use ONI V Rego Products, 3119A, 3120 and 3121 Unloading Adapters with Rego Products Filler Valves. Carefully follow the instructions supplied with these unloading adapters. If container is not being placed into service at the present time, insert plug or cap onto the outlet connection. In selecting a label for posting at the installation site, consider ECIL "part number 901-400 or 903-400 along with your own, NPGAs and others. Remember to instruct the owner/user/customer in safety matters concerning LP-Gas and this equipment. See ECIL "Safety Warnings—LP-Gas Cylinder Valves", "LP-Gas Excess Flow Valves", and "LP-Gas Filler and Hose End Filling Valves" found in the cylinder valve, excess flow valve, and filler valve sections of the L-500 & L-102 Catalogs. Engineered Controls International, Inc., ECIL "requests that this information be forwarded to your customers. Additional copies are available from ECIL " and your authorized ECIL " Product Distributor. **REGO** Printed in USA 08-0809-0686 Part number 903-500 100 Rego Drive PO Box 247 Elon, NC 27244 USA Phone (336) 449-7707 Fax (336) 449-6594 www.regoproducts.com

B18